


# ECM-HS1

## SERVICE MANUAL

*US Model  
Canadian Model  
AEP Model  
UK Model*



This set does not support the repair of individual faulty parts.  
In case of failure, the main assembly must be replaced.  
The part code of main assembly is as listed below.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
1	A-7007-007-A	MAIN ASSY (US, Canadian model)
1	A-7007-008-A	MAIN ASSY (AEP, UK model)
2	3-969-252-01	WIND SCREEN
	3-970-278-01	PORCH
	3-856-380-11	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, GERMAN)
	3-856-380-21	MANUAL, INSTRUCTION (DUTCH, SWEDISH, ITALIAN, PORTUGUESE)
	3-856-380-31	MANUAL, INSTRUCTION (RUSSIAN, CHINESE)

**ELECTRET CONDENSER MICROPHONE**  
**SONY®**



9-973-868-11

**Sony Corporation**  
**Consumer A & V Products Company**  
**Personal A & V Products Div.**

English  
96C0482-1  
Printed in Japan  
© 1996. 3

Published by Personal A & V Products Div.  
Quality Engineering Dept.